




Visite la página TRAXXAS.com/manuals para descargar el instructiones en su idioma.

Auf TRAXXAS.com/manuals können Sie anleitung in Ihrer Sprache downloaden.


#### Low-CG Chassis Conversion Instructions

## Covers Part #5830

# CHASSIS COMPONENT INSTALLATION




## **VEHICLE ASSEMBLY**



## **SERVO MOUNTING POSITIONS**

#### **HIGHER POSITION**


FOR VEHICLES WITH SERVO-MOUNTED SERVO SAVERS



#### **LOWER POSITION**

FOR VEHICLES WITH BELLCRANK-MOUNTED SERVO SAVERS

SERVO ARM USED WHEN MOUNTING



#### Reversing the direction of the steering servo (TQi transmitter):

- 1. Press and hold MENU. Green LED blinks.
- 2. Press MENU. Green LED blinks 2 times.
- 3. Press SET. Green LED blinks.
- 4. Press SET. Red LED blinks.
- 5. Press SET to reverse servo direction. Green LED blinks 8 times.
- 6. Press and hold MENU.

### Reversing the direction of the steering servo (TQ 2.4GHz transmitter):

- 1. Press and hold SET. Green LED blinks.
- 2. Turn steering wheel to full left or full right.
- 3. Hold steering wheel in position.
- 4. Press SET to reverse servo direction.





\*\*VXL equipped models only

