

Exploded View Parts Listing

Ref	Part	Component	Ref	Part	Component
001	EFLH1150	Flybar Paddle	053	EFLH1409	Pinion 9T
002	EFLH1165	Flybar Weight 1.6 x 6 x 5mm	054	EFLH1514	Pan Head Screw 3 x 6mm
003	EFLH1148	Flybar Retaining Collar 3 x 7 x 5mm	055	EFLH1517	Motor Mount
004	EFLH1149	Flybar 1.5 x 200mm	056	EFLH1516	Brushless Motor
005	EFLH1148	Paddle Control Frame	057	EFLH1514	Pan Head Screw 2 x 6mm
006	EFLH1146	Rotor Head Frame B	058	EFLH1503	Tail Boom Blue 7x 8 x 271mm
007	EFLH1512	Center Hub Cap	059	EFLH1507	Tail Motor Wire Lead
008	EFLH1146	Rotor Head Frame A	060	EFLH1506	Lower Horz. Fin Mount
009	EFLH1146	Rotor Head	061	EFLH1506	Upper Horz. Fin Mount
010	EFLH1512	Center Hub	062	EFLH1326W	Horizontal Fin
011	EFLH1513	O-Ring 2 x 6mm	063	EFLH1326W	Vert Fin
012	EFLH1151	Pitch Control Link	064	EFLH1505	Tail Motor Mount
013	EFLH1151	Pitch Control Rod 1.4 x 10mm	065	EFLH1514	Flat Washer 2 x 4 x 0.4mm
014	EFLH1523	Spindle	066	EFLH1514	Pan Head Screw 1.6 x 3mm
015	EFLH1163	Paddle Control Frame Pushrod	067	EFLH1323	Tail Rotor Adapter
016	EFLH1512	Socket Head Cap Screw 2 x 9mm	068	EFLH1324	Tail Rotor Blade
017	EFLH1513	Shim 3.1 x 5.6 x 0.1mm	069	EFLH1514	Flat Washer-Special 2 x 8 x 1.2mm
017	EFLH1172	Shim 3.1 x 5.6 x 0.1mm	070	EFLH1322	Tail Motor
018	EFLH1171	Step Washer 3.1 x 5.5 x 0.5mm	071	EFLH1319	Tail Motor Heat Sink
019	EFLH1150	Pan Head Screw 2 x 6mm	072	EFLDS75H	Servos
020	EFLH1514	Setscrew 3 x 3mm	073	EFLH1515	Control Ball
021	EFLH1514	Nut 2mm	074	EFLH1514	Flat Head CS Screw
022	EFLH1514	Pan Head Screw 2.6 x 6mm	075	EFLH1514	Nylock Nut 2mm
023	EFLH1115	Bearing 3x 6 x 2.5mm	076	EFLRG110HL	Gyro
024	EFLH1514	Pan Head Screw 1.4 x 3mm	077	EFLA308H	ESC
025	EFLH1171	Brass Spacer 3.1 x 4 x 3.1mm	078	EFLH1514	Hook & Loop Strap
026	EFLH1172	Bell Mixer Arm Pushrod	079	EFLH0997	1000mAh 3-Cell Li-Po Battery
027	EFLH1171	Blade Grip	080	EFLH1520	Canopy
028	EFLH1514	Socket Head Cap Screw 2 x 12mm	081	SPMAR6110E	Receiver
029	EFLH1518	Blades	082	EFLH1519	Blade Holder
030	EFLH1514	Flat Washer 2.2 x 5 x 0.5mm	083	EFLH1522	Canopy Grommet
031	EFLH1514	Socket Head Cap Screw 2 x 6mm			
032	EFLH1172	Bell Mixer Arm			
033	EFLH1172	B/M Arm Bushing 2.9 x 3.4 x 7mm			
034	EFLH1514	Washer- Special 1.8 x 5.2 x 0.1mm			
035	EFLH1514	Pan Head Screw 1.7 x 4mm			
036	EFLH1511	Swashplate			
037	EFLH1508	Main Shaft 4 x 79mm			
038	EFLH1510	Main Shaft Collar			
039	EFLH1515	Servo Pushrod 1.6 x 16mm			
040	EFLH1515	Servo Pushrod Link			
041	EFLH1515	Servo Pushrod 1.6 x 28mm			
042	EFLH1215	Main Shaft Brg 4 x 8 x 3mm			
043	EFLH1509	Main Gear 140T			
044	EFLH1501	Right Frame			
045	EFLH1501	Left Frame			
046	EFLH1514	Pan Head Screw 1.7 x 6mm			
047	EFLH1514	Socket Head Cap Screw 2 x 10mm			
048	EFLH1524	Anti-Rotation Bracket			
049	EFLH1522	Canopy Mount Rod 2 x 30mm			
050	EFLH1522	Canopy Mount Ends			
051	EFLH1502	Landing Gear Asm			
052	EFLH1514	Pan Head Screws 1.6 x 6mm			

Exploded View

